



Installation Instructions  
Diamond Brite Taillight Kit  
Part # 5307

Step # 1

Remove taillight lens, 4 screws  
remove Bulbs, (note there are two  
different bulbs) and Center Divider;  
it is not necessary to remove the  
housing from the vehicle.



Step # 2

Insert new reflector,  
line up tabs on both  
sides of housing,  
reflector may be snug,  
but will slide in tightly.



Step # 3

Install bulbs and the new lens  
You're done, Enjoy your  
new look.

