



QUALITY... PLAIN & SIMPLE®

Lokar Billet Aluminum Dimmer Switch Cover Installation Instructions

TOLL FREE 1-877-469-7440
tech@lokar.com • www.lokar.com

General Installation Notes:

Please read these instructions completely before beginning the installation. If you have any questions please call.

Before beginning the installation, disconnect the negative battery cable and use wheel chocks to block the vehicle's wheels.

We recommend using anti-seize lubricant on all aluminum threads.

- Step 1:** Loosen the #10-24 x 3/16" set screws in the Dimmer Switch Cover using a 5/64" Allen wrench. The set screws do not need to be removed, just loosened enough for the Dimmer Switch Cover to fit over the dimmer switch.
- Step 2:** Place the Dimmer Switch Cover onto the dimmer switch, and determine how you would like it to be positioned.
- Step 3:** Once you have it positioned the way you want it, tighten the set screws until they are just snug. **DO NOT** overtighten the set screws.

