



## WP111 Small Block Ford (260, 289, 302, 351W, 351C, 351/ 400M)

**\*Order backing plate according to your timing cover model**

### **In The Box You Will Find:**

- 1 Electric Water Pump
- 4 5/16 – 18 x 3 1/2" stainless socket head bolts
- 4 5/16 AN washers
- 2 Flange gaskets
- 1 1" npt plug
- 1 Wiring harness w/ 20 amp fuse
- 2 Contingency stickers

**The inlet fitting must be ordered separately to match your lower radiator hose or AN fitting**

### **To Do The Job You Will Need:**

- Scraper or wire brush
- Brake cleaner
- Sealant; Form A Gasket ( Aviation ), Form A Gasket 2 ( Non-Hardening ), Gaskacinch or RTV silicone
- Thread sealant; RTV silicone or liquid pipe thread sealant
- 5/16" hex socket
- Spanner wrench or see **Inlet** section for substitute procedure

### **Mounting The Back Plate**

Remove stock water pump, clean and degrease the gasket surface. Apply sealant to both sides of factory gasket and tack to the backside of the Meziere back plate P/N WP112 / WP113 / WP123. Align gasket to bolt holes and bolt to timing cover using 3/4" x 5/16" – 18 hardware provided.

### **Mounting Pump**

Be sure to use a proper sealant on both sides of the mounting flange gaskets. Bolt pump in place using 3-1/4 x 5/16 - 18 provided. **Run all four bolts up snug before tightening to 30 ft./ lbs.**

### **Running**

Fill the cooling system. Replace fill cap and turn on pump. Remove fill cap and top off coolant level. Recheck level after one heat cycle. **DO NOT RUN PUMP DRY for more than a few seconds.**

### **Inlet**

Our hose inlets are designed to be tightened using a spanner wrench. It is necessary to use a small amount of RTV silicone or liquid pipe thread sealant on the 1" pipe threads of the inlet and the plug to prevent leaks.

### **Wiring**

The **BLUE** wire connects to **positive (+)**

The **BLACK** wire connects to chassis ground or battery **negative (-)**

**TO AVOID MOTOR FAILURE**, be sure to use the fuse holder supplied with the harness or install your own 10 to 20 amp fuse and holder.

### **Beauty Tip**

Your pump comes to you polished and waxed. An occasional waxing will allow dirt or debris to be wiped right off the pump and also offer some protection from UV light (the anodized color on your pump can fade from prolonged exposure to sunlight).

Thank you for purchasing our product. Feel free to contact us if we can be of further assistance and enjoy your pump for a long, long time.



**WARNING: NOT USING A FUSE CIRCUIT WILL VOID YOUR WARRANTY.**

**220 S. Hale Ave. ~ Escondido, CA 92029 ~ (760) 746-3273 ~ FAX 746-8469**