





INSTALLATION INSTRUCTIONS

P/N 23000 – OIL PAN BAFFLE SMALL BLOCK and 90° V-6 CHEVY P/N 23010 – OIL PAN BAFFLE BIG BLOCK CHEVY

This baffle is designed to hold down surging oil during acceleration and will be a snug fit in the oil pan. Minor trimming may be necessary with certain oil pans. Some Chevy H.P. crankshafts have large counterweights which may scrape the anti-surge baffle. Reshaping or trimming the baffle will correct this.

The Moroso Part #2300 and #23010 Oil Pan Baffle should be installed against the rear main bearing cap in all cases. Check carefully for fit and clearance before final assembly.

When using with a main cap stud kit, it may be necessary to drill two 7/16" holes in the baffle for clearance.

INSTALLATION INSTRUCTIONS

P/N 23000 – OIL PAN BAFFLE SMALL BLOCK and 90° V-6 CHEVY P/N 23010 – OIL PAN BAFFLE BIG BLOCK CHEVY

This baffle is designed to hold down surging oil during acceleration and will be a snug fit in the oil pan. Minor trimming may be necessary with certain oil pans. Some Chevy H.P. crankshafts have large counterweights which may scrape the anti-surge baffle. Reshaping or trimming the baffle will correct this.

The Moroso Part #2300 and #23010 Oil Pan Baffle should be installed against the rear main bearing cap in all cases. Check carefully for fit and clearance before final assembly.

When using with a main cap stud kit, it may be necessary to drill two 7/16" holes in the baffle for clearance.

INSTALLATION INSTRUCTIONS

P/N 23000 – OIL PAN BAFFLE SMALL BLOCK and 90° V-6 CHEVY P/N 23010 – OIL PAN BAFFLE BIG BLOCK CHEVY

This baffle is designed to hold down surging oil during acceleration and will be a snug fit in the oil pan. Minor trimming may be necessary with certain oil pans. Some Chevy H.P. crankshafts have large counterweights which may scrape the anti-surge baffle. Reshaping or trimming the baffle will correct this.

The Moroso Part #2300 and #23010 Oil Pan Baffle should be installed against the rear main bearing cap in all cases. Check carefully for fit and clearance before final assembly.

When using with a main cap stud kit, it may be necessary to drill two 7/16" holes in the baffle for clearance.

For Technical Assistance, Call Moroso's Tech Line at (203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time

MOROSO PERFORMANCE PRODUCTS, INC 80 CARTER DR • GUILFORD, CT 06437 Phone: (203) 453-6571 • Fax: (203) 453-6906

VIsItUsAtwww.moroso.com

For Technical Assistance, Call Moroso's Tech Line at (203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time

MOROSO PERFORMANCE PRODUCTS, INC 80 CARTER DR • GUILFORD, CT 06437

Phone: (203) 453-6571 • Fax: (203) 453-6906

VIsItUsAtwww.moroso.com

For Technical Assistance, Call Moroso's Tech Line at (203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time

MOROSO PERFORMANCE PRODUCTS, INC 80 CARTER DR • GUILFORD, CT 06437

Phone: (203) 453-6571 • Fax: (203) 453-6906

VIsItUsAtwww.moroso.com

Rev. D 23000INST Rev. D 23000INST Rev. D 23000INST Rev. D 23000INST