



P/N 72130, 72131, 72132, 72133 WIRE LOOM KIT

Secures spark plug wires to keep them protected from crossfire and hot engine components.

Slight modifications are required to fit 8.5mm to 11mm wire or wire fitted with Moroso Insulating Sleeve.

INSTALLATION

1. Install Chrome Plated Brackets onto valve cover mounting studs.
2. Attach appropriate 2, 3, or 4-hole Loom to each Chrome Plated Bracket.
3. Simply "snap" wires into Looms. (silicone spray lubricant helps ease the wires into the openings).
4. Route the wires neatly to the distributor and add 2, 3, or 4-hole Wire Separators where desired.
5. If using wire larger than 8mm or wire with Moroso Insulating Sleeve, file the "nubs" on the Separators and Looms to the size you need to hold wire securely. 72130INST

For Technical Assistance, Call Moroso's Tech Line at (203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Rev.C
013112

Visit Us At www.moroso.com



P/N 72130, 72131, 72132, 72133 WIRE LOOM KIT

Secures spark plug wires to keep them protected from crossfire and hot engine components.

Slight modifications are required to fit 8.5mm to 11mm wire or wire fitted with Moroso Insulating Sleeve.

INSTALLATION

1. Install Chrome Plated Brackets onto valve cover mounting studs.
2. Attach appropriate 2, 3, or 4-hole Loom to each Chrome Plated Bracket.
3. Simply "snap" wires into Looms. (silicone spray lubricant helps ease the wires into the openings).
4. Route the wires neatly to the distributor and add 2, 3, or 4-hole Wire Separators where desired.
5. If using wire larger than 8mm or wire with Moroso Insulating Sleeve, file the "nubs" on the Separators and Looms to the size you need to hold wire securely. 72130INST

For Technical Assistance, Call Moroso's Tech Line at (203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Rev.C
013112

Visit Us At www.moroso.com



P/N 72130, 72131, 72132, 72133 WIRE LOOM KIT

Secures spark plug wires to keep them protected from crossfire and hot engine components.

Slight modifications are required to fit 8.5mm to 11mm wire or wire fitted with Moroso Insulating Sleeve.

INSTALLATION

1. Install Chrome Plated Brackets onto valve cover mounting studs.
2. Attach appropriate 2, 3, or 4-hole Loom to each Chrome Plated Bracket.
3. Simply "snap" wires into Looms. (silicone spray lubricant helps ease the wires into the openings).
4. Route the wires neatly to the distributor and add 2, 3, or 4-hole Wire Separators where desired.
5. If using wire larger than 8mm or wire with Moroso Insulating Sleeve, file the "nubs" on the Separators and Looms to the size you need to hold wire securely. 72130INST

For Technical Assistance, Call Moroso's Tech Line at (203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Rev.C
013112

Visit Us At www.moroso.com



P/N 72130, 72131, 72132, 72133 WIRE LOOM KIT

Secures spark plug wires to keep them protected from crossfire and hot engine components.

Slight modifications are required to fit 8.5mm to 11mm wire or wire fitted with Moroso Insulating Sleeve.

INSTALLATION

1. Install Chrome Plated Brackets onto valve cover mounting studs.
2. Attach appropriate 2, 3, or 4-hole Loom to each Chrome Plated Bracket.
3. Simply "snap" wires into Looms. (silicone spray lubricant helps ease the wires into the openings).
4. Route the wires neatly to the distributor and add 2, 3, or 4-hole Wire Separators where desired.
5. If using wire larger than 8mm or wire with Moroso Insulating Sleeve, file the "nubs" on the Separators and Looms to the size you need to hold wire securely. 72130INST

For Technical Assistance, Call Moroso's Tech Line at (203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Rev.C
013112

Visit Us At www.moroso.com



P/N 72130, 72131, 72132, 72133 WIRE LOOM KIT

Secures spark plug wires to keep them protected from crossfire and hot engine components.

Slight modifications are required to fit 8.5mm to 11mm wire or wire fitted with Moroso Insulating Sleeve.

INSTALLATION

1. Install Chrome Plated Brackets onto valve cover mounting studs.
2. Attach appropriate 2, 3, or 4-hole Loom to each Chrome Plated Bracket.
3. Simply "snap" wires into Looms. (silicone spray lubricant helps ease the wires into the openings).
4. Route the wires neatly to the distributor and add 2, 3, or 4-hole Wire Separators where desired.
5. If using wire larger than 8mm or wire with Moroso Insulating Sleeve, file the "nubs" on the Separators and Looms to the size you need to hold wire securely. 72130INST

For Technical Assistance, Call Moroso's Tech Line at (203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Rev.C
013112

Visit Us At www.moroso.com



P/N 72130, 72131, 72132, 72133 WIRE LOOM KIT

Secures spark plug wires to keep them protected from crossfire and hot engine components.

Slight modifications are required to fit 8.5mm to 11mm wire or wire fitted with Moroso Insulating Sleeve.

INSTALLATION

1. Install Chrome Plated Brackets onto valve cover mounting studs.
2. Attach appropriate 2, 3, or 4-hole Loom to each Chrome Plated Bracket.
3. Simply "snap" wires into Looms. (silicone spray lubricant helps ease the wires into the openings).
4. Route the wires neatly to the distributor and add 2, 3, or 4-hole Wire Separators where desired.
5. If using wire larger than 8mm or wire with Moroso Insulating Sleeve, file the "nubs" on the Separators and Looms to the size you need to hold wire securely. 72130INST

For Technical Assistance, Call Moroso's Tech Line at (203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Rev.B
013112

Visit Us At www.moroso.com