

### 2016+ Nissan Titan Hood Light Brackets

Congratulations on your purchase of a high quality PUTCO product. Should you need any application or technical assistance, feel free to call us at: 1-800-247-3974

Monday-Friday 8:00 a.m. - 5:00 p.m. (Central Standard Time)

Contact your PUTCO dealer for other quality accessories.

Please read all instructions before installation and to check to see that all parts are included.

KIT CONTENTS:	
Description	Qty.
Driver Side Bracket	1
Passenger Side Bracket	1

#### Tools Needed:

- Socket set
- 12mm socket

#### ***Installation Instructions:***

The brackets are designed to utilize the factory mounting locations for the hood hinge. These locations are shown in **Figure 1**.



**Figure 1: Bracket Locations**

### Installation Instructions Cont.

1. Begin by using a 12mm socket to loosen the top nut holding the hood to the hinge. **It is important to only do one side of the hood at a time to prevent damage to the hood.** It may also be helpful to mark the bracket and hood with a marker before you begin loosening to use as a reference for aligning the hood.
2. Loosen the bottom and top nuts. Completely removing the nuts is not necessary as the brackets are slotted for ease of installation.
3. Slide the bracket in place as shown in **Figure 2**.
4. Tighten the nuts while making sure the hood is aligned as it was before the bracket was loosened.
5. Repeat steps 1-4 on the other side of the vehicle.
6. Mount light in top hole of bracket (this kit is designed for Putco 10004 or 10007 LED Block Lamps)

