

**20-inch Single Row LED Light Bar
Hidden Bumper Mount
Chevrolet: 07-13 Silverado 1500 4WD/2WD**

Parts:

1 - Light Bracket
2 - 8mm Bolts

PRE-INSTALLATION

Professional installation by a certified technician is strongly recommended.

Not responsible for altered products. No claims are made regarding any after-market devices. Any and all claims implied in this document excluded.

NOTES:

Light bar not included in kit. Only fits 2007-2013 Chevrolet 1500.

REQUIRED TOOLS:

13mm Wrench 10mm Socket Flat Blade Screwdriver

INSTALLATION INSTRUCTIONS

- STEP 1:** Disconnect positive battery lead before installation.
- STEP 2:** Remove three bolts behind bumper opening. (10mm Socket)
- STEP 3:** Remove push pins holding rubber air flap. (Save push pins for reinstallation)
- STEP 4:** Push air flap down.
- STEP 5:** Place bracket through bumper opening. Reinstall three factory bolts. (Do not tighten)
- STEP 6:** Install light bar in bracket using included 8mm bolts.
- STEP 7:** Center light bar in opening and tighten three factory bolts holding bracket.
- STEP 8:** Replace rubber air flap and secure with factory push pins.
- STEP 9:** Set light bar to desired angle and tighten 8mm bolts.
- STEP 10:** Wire power to light bar per instructions supplied with kit.
- STEP 11:** Reconnect positive battery lead.

POST-INSTALLATION

MAINTENANCE: Periodically check to ensure that all fasteners are properly tightened.