

Ford-Chevy-GMC 2WD/4WD 0.25" Wheel Spacer; 6x5.5"; 6x135mm

Parts:

2 - 1/4" Wheel Spacers

PRE-INSTALLATION

Professional installation by a certified technician is strongly recommended.

Not responsible for altered products. No claims are made regarding any lifting devices. Any and all claims implied in this document excluded.

NOTES:

Check spacers regularly to ensure tightness.

REQUIRED TOOLS:

Floor Jack

Jack Stands

Torque Wrench

Socket Set

Socket Wrench

INSTALLATION INSTRUCTIONS

STEP 1: Chock tires to avoid vehicle roll. Jack up vehicle so that wheels are just off the ground.

STEP 2: Remove all lug nuts. (Socket wrench)

STEP 3: Remove wheels/tires.

STEP 4: Check for factory retaining clips and remove if present. Wheel spacer must sit flat against the rotor. Vibrations may occur if clips are not removed from wheel studs.

STEP 5: Install wheel spacers on studs.

STEP 6: Re-install wheels/tires.

STEP 7: Re-install lug nuts and tighten to factory specs. (Torque wrench) **DO NOT OVERTIGHTEN**

POST-INSTALLATION

MAINTENANCE: Wheel lug nuts should be re-tightened to factory torque specs. periodically. Always inspect components and re-tighten lug nuts during routine service.