

ROUGH COUNTRY

SUSPENSION SYSTEMS®

GMC 2014-15 1500 Mesh Grille

Thank you for choosing Rough Country for all your lighting needs.

▲ NOTICE

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go. If question exist, please call us @ 1-800-222-7023. We will be happy to answer any questions concerning the design, function, and correct use of our products.

▲ NOTICE


Only fits 2014-15 GMC 1500 models.

Tools Needed:

7mm Socket
 10mm Socket/Wrench
 Flat Screwdriver
 Reciprocating Saw
 9/32" Drill
 Drill Motor
 7/16" Socket
 7/16" Wrench
 5/32" Allen Wrench
 Ratchet
 Tape

Kit Contents

- (1) Grille Trim Ring
- (1) Mesh Grille
- (1) Instructions
- (7) LH Mounting Brackets
- (6) RH Mounting Brackets
- (1) 70188BAG
 - (26) 1/4" x 5/8" Button Head Allen Bolts
 - (14) 1/4" x 1/2" Button Head Allen Bolts
 - (40) 1/4" Lock Nuts
 - (13) 1/4" Flat Washers





1. Park the vehicle on a smooth level surface.
2. **▲ NOTICE** Fender flares will need to be removed. GMC models will need the fender trim removed.
3. Using a 7mm socket, remove the bolts, from inside the fender well, holding the upper fascia. Save for reuse. **See Photo 1.**
4. Remove the upper bumper fascia by gently pulling from front of truck. **See Photo 2.**




5. Using a flat screwdriver remove the push pins from the radiator cover. Save for reuse. **See Photo 3.**
6. Remove the radiator cover from the truck. **See Photo 4.**




7. Using a 10mm socket, remove the (4) upper grille mounting bolts. Save for reuse. **See Photo 5.**
8. Using a 10mm socket, remove the lower grille mounting bolts. Save for reuse. **See Photo 6.**





9. Remove the grille by gently pulling from front of truck. **See Photo 7.**
10. Lay the grill face down, on a towel or soft surface to keep from scratching the paint. **See Photo 8.**



11. Using a 10mm socket, remove the inner grille. **See Photo 9.**
12. Remove the inner grille and set aside for re-use. **See Photo 10.**




13. Using a reciprocating saw, cut the horizontal grille bars. **See Photo 11.**
14. Using a reciprocating saw, cut the vertical grille bars. **See Photo 12.**





15. Remove the grille from the grille trim. Use a file or sandpaper to smooth the cut areas from the grille trim. **See Photo 13.**
16. Flip the grille trim face up and place tape along the painted edges to prevent scratches. **See Photo 14.**



17. Lay the supplied mesh grille trim ring face down, then lay the mesh grille facedown on top of the trim ring.
18. Standing over the grille on the bottom side. Place the mounting brackets as shown in **Photo 15**, using the supplied 1/4" x 5/8" bolts and nuts, washers will not be used on these bolts. **Do Not Tighten, only snug for future adjustment.**
19. Attach the grille trim to the mesh using the supplied 1/4" x 1/2" bolts and nuts. Tighten using a 5/32" Allen and 7/16" socket/wrench.
20. Mark holes to be drilled. **You may have to bend the tabs and grille slightly to match the grille trim. See Photo 16.**




21. Using a 9/32" drill, drill the mounting holes in the grille trim. **See Photo 17. You may have to bend the mesh grille to follow the lines of the factory grille trim, as the mesh grille is shipped as flat pieces.**
22. Place assembled mesh grille back into the grille trim. **See Photo 18.**





23. Attach the mesh grille to the grille trim using the supplied 1/4" x 5/8" bolts, nuts, and washers. The washers will go between the bolt head and the plastic of the grille trim. **Tighten all bolts using a 7/16" wrench and socket.**
24. Attach the inner grille to the grille trim using the factory hardware. **See Photos 19 & 20.**



25. Use a 10mm socket to tighten the inner grille bolts. **See Photo 21.**
26. Install the grille assembly onto the truck making sure all clips are firmly seated. **See Photo 22.**




27. Using the factory hardware and a 10mm socket, attach the grille assembly to the radiator support. **See Photos 23 & 24.**



28. Install the radiator cover using the factory hardware. **See Photo 25.**

29. Install the bumper fascia making sure it is securely fastened into the factory clips. **See Photo 26.**



30. Install the fender trim and fender flares if used. **See Photo 27.**



By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable , State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

