

# ROUGH COUNTRY

## SUSPENSION SYSTEMS®

### JEEP JL Steering Stabilizer

#### KIT CONTENTS:

1-Stabilizer Cylinder

#### TOOLS NEEDED:

18mm Socket  
Torque Wrench

#### TORQUE SPECS:

12mm 55 ft/lbs - 75 ft/lbs

#### STABILIZER INSTALLATION INSTRUCTIONS

1. Remove the factory stabilizer from the axle using a 18mm socket. Retain the factory hardware for reuse. **See Photo 1.**
2. Remove the factory stabilizer from the from the tie rod mount using a 18mm socket. Retain the factory hardware for reuse. **See Photo 2.**



PHOTO 1



PHOTO 2

3. Install the rod end of the stabilizer in the tie rod mount using the factory hardware. Tighten using an 18mm socket. Torque to 75ft/lbs. **See Photo 3.**
4. Install stabilizer in the axle mount with the factory hardware. Tighten using an 18mm socket. Torque to 75ft/lbs. **See Photo 4.**



PHOTO 3



PHOTO 4

By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable , State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

