

Installation Instructions <u>P/N 42736 (chrome) - P/N 42736G (bronze)</u> <u>P/N 42736K (black) - P/N 42736S (silver)</u>

Step 1

Place the cap cover onto the factory washer fluid cap and press firmly to install until the tabs engage fully around the stock cap.

ATTENTION: Do not use harsh chemicals to clean covers.

If you have any difficulties or questions regarding the installation of this part, contact the Spectre Performance Technical Department by email - Tech@spectreperformance. com or by phone 1-909-673-9800 Monday thru Friday 6:00am to 2:00pm PST.

