



2016 Camaro Plate Installation

Hardline Plate System Instructions

Part #'s 00-10154

INSTALLATION INSTRUCTIONS

****Never use teflon tape! only use red or blue loc-tite on NPT fittings, AN fittings are meant to seat and seal on the bevel****

Step 1: Disconnect the positive terminal on the battery

Step 2: Release all the pressure from the vehicles fuel system by removing the gas cap.

Step 3: Remove the engine cover and breather hoses in front of the cover to have easy access to the throttle body.

Step 4: Unplug the TPS plug on the left side and remove the air inlet hose(s).

Step 5: Remove the 4 bolts holding the throttle body to the intake manifold.

Step 6: Attach the throttle body to the spacer with the solenoids on the driver side and open fittings on solenoids facing towards the firewall mounting it back on the intake manifold.

Step 7: Remove the quick disconnect fuel line and install the quick disconnect fuel adapter supplied with your kit. using the supplied 3AN to 4AN hose connect the fuel solenoid to the fuel adapter.

Step 8: You may use the WOT switch supplied and make a bracket to the throttle pedal but it is highly recommended to install a nitrous controller that allows you regulate your switch thru the TPS because of the Drive-By-Wire system.

Step 9: Route your relay and wiring accordingly to the diagram provided.

Step 10: Lastly route the stainless line from the nitrous solenoid through the firewall and to your nitrous bottle.

