

## INSTALLATION INSTRUCTIONS

### **96-04 NISSAN PATHFINDER REAR BUMPER GUARD Part#:**

NO.	Description	Cat.No	Req.No.
1	Read Bumper		1
2	Hex bolts	M12×40	4
3	Nylock nut	M12	4
4	Flat Washer	12	8

## ASSEMBLY

### **BEFORE ANY ASSEMBLING CHECK OUT ALL PARTS:**

1. Read the whole instruction before beginning.
2. Mount the rear bumper guard holes onto outside of vehicle frame. If necessary do it by holding the rear bumper guard.
3. Remove the bolts on per side that fasten strap-down bracket.
4. Align the bumper with the over holes and mount it with the existing hardware.  
BE AWARE that the wag rear bumper guard designed to accommodate factory hitch packages. If a factory tow hitch requires the same holes of the rear bumper guard remove only the bolts needed. Do not remove the whole package. Mount the rear bumper guard with the M12 bolts an M12 locknuts.
5. Adjust and tight up all the bolts for complete Installation.

