



3204 & 7204 Installation Instructions

2013 Dodge 3500 Pickup 4WD

2014 Dodge 2500 Pickup 4WD

Steering Stabilizer

Live Chat @ www.zoneoffroad.com • *Website* www.zoneoffroad.com • *Email* tech@zoneoffroad.com • *Call* 888.998.ZONE

Read and understand all instructions and warnings prior to installation of product and operation of vehicle.

Difficulty Level

easy (1) 2 3 4 5 difficult

Estimated installation: .5 hours

» PRODUCT SAFETY WARNING

Certain Zone Suspension Products are intended to improve off-road performance. Modifying your vehicle for off-road use may result in the vehicle handling differently than a factory equipped vehicle. Extreme care must be used to prevent loss of control or vehicle rollover. Failure to drive your modified vehicle safely may result in serious injury or death. Zone Offroad Products does not recommend the combined use of suspension lifts, body lifts, or other lifting devices.

You should never operate your modified vehicle under the influence of alcohol or drugs. Always drive your modified vehicle at reduced speeds to ensure your ability to control your vehicle under all driving conditions. Always wear your seat belt.

Installation Instructions

1. Park vehicle on a clean, flat surface and block the rear wheels for safety.
2. Disconnect the factory steering stabilizer for the axle and tie rod mounts. Save hardware.
3. Locate the provided bushings and sleeves. There is a 1-1/2" wide bushing/sleeve set and a 1-3/8" wide bushing/sleeve set. Lightly grease and install the 1-1/2" wide set in the ROD end of the stabilizer and the 1-3/8" set in the BODY end.
4. Install the new stabilizer in the factory mounts with the original hardware. The BODY end of the stabilizer will mount to the axle. Torque hardware to 55 ft-lbs.
5. Apply provided sticker and check hardware for proper torque.
6. Cycle steering to verify proper clearance.

rev121613