



C5202 Installation Instructions 2011-16 GM 2500/3500 HD 4WD Shock Extension Kit

Read and understand all instructions and warnings prior to installation of product and operation of vehicle.

Zone Offroad Products recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

C5202 Box Kit Contents

Qty	Part
4	Upper Shock Spacer
4	12mm nut
8	1/2" SAE washer

Difficulty Level

easy **1** 2 3 4 5 difficult

Estimated installation: 1/2 hour

Special Tools Required

None

PRE-INSTALLATION NOTES

1. These instructions are written assuming the truck already has a 2" leveling kit installed.

INSTALLATION INSTRUCTIONS

1. Park vehicle on clean, flat, and level surface. Block the rear wheels for safety.
2. Remove the upper shock nuts and lower shock bolt. Remove shocks from vehicle.
3. Install the provided shock extension sleeves over the factory bar pin studs. Reinstall the shock in the vehicle with provided 12mm nuts and 1/2" SAE washers. Leave hardware loose.
4. Reattach the lower shock mount with factory bolt and nut. Tighten to 95 ft-lbs. Torque the upper hardware to 60 ft-lbs.
5. Verify all hardware is properly torqued.