

Installation Instructions for 23660 Oil Gauge Block Adapter

BE CAREFUL – DO NOT OVERTIGHTEN THE THREADED FITTINGS! Use liquid Teflon thread sealing compound to avoid leaks and to guard against galling of threads.

Installation Instructions:

1. Locate the desired oil pressure gauge port.
2. Install the gauge adapter into the oil pressure gauge port.
3. Install your desired gauge or sending unit (not included) making sure there is no interference with any moving parts.



1-800-345-4545 jeps.com