

## ***Installation Instructions for 80521 Stud Mount Valve Spring Compressor***

For use with: 3/8"-24 and 7/16"-20 studs

### **Instructions for reversing threaded plunger:**

1. Determine which end of the plunger is to be used. One end has 3/8"-24 threads and one end has 7/16"-20 threads. To interchange the plunger remove the 1/4" snap ring, remove the 1/4" clevis pin and rotate end for end. Reverse the above procedure to reassemble.



**1-800-345-4545 [jeps.com](http://jeps.com)**