


## Installation Instructions for 10244 Replacement Latches

for 555-10240 thru 10243 Aluminum Battery Boxes







When the upper latch tab is in position and the spring-lock is protruding, simply push the lower latch end all the way down and the spring-lock will pop into place and secure the box. To open simply apply slight pressure upward on the spring-lock to release tension.

