

Installation Instructions for 150292 Vacuum Secondary Spring Kit

Changing secondary spring to achieve better performance is a relatively simple procedure. Best acceleration is achieved when you cannot feel the secondaries open. If you can feel the secondaries physically open, that feeling is a hesitation. Change to a heavier spring until the hesitation is eliminated.

<u>Color</u>	<u>Compression</u>
---------------------	---------------------------

White.....	Lightest
Yellow (short).....	Lighter
Yellow (long).....	Light
Purple.....	Medium
Plain.....	Heavy
Brown.....	Heavier
Black.....	Heaviest



1-800-345-4545 jeps.com