

Installation Instructions for 52190 to 52194 Light Weight Mechanical Fan

Installation Instructions:

WARNING! Read carefully before installing fan to avoid possible error, damage, or injury.

1. Measure the diameter of your old fan, and make sure the new fan diameter is the same. This diameter is measured from tip to tip on opposing blades.
2. Remove old fan.
3. Install your new JEGS fan on the water pump hub, use spacers such as JEGS #555-51190 thru #555-51197 if required and proper length bolts and washers.

NOTE: Be sure to use supplied flat washers and lock washers where shown in diagram.

4. Loosen fan belt, rotate fan to insure the following clearances.
 - a. 1" between each blade tip and the closest obstruction to the outer diameter of the fan.
 - b. 1-1/2" to 2" minimum distance between the front of the fan and the closest obstruction forward.
 - c. 1/2" minimum distance between fan and closest obstruction behind.
5. Adjust fan belt.

