

Installation Instructions for 65029 JEGS Pro Digital Air Gauge (0-50psi)

OPERATING INSTRUCTIONS

On/Off: Press ON/OFF to toggle on and off. Device will automatically shut off after 20 minutes if not used.



Zero: Zeros the display - Push & hold for 2 seconds to zero the display. Do not use the zero button when pressure is applied.



Units: To change units, press both On/Off and Zero buttons simultaneously.



Overpressure Indicator: The LCD will flash "OFL", if the pressure applied is over 105% F.S.

Temperature Limits: 30 to 120°F (-1 to 49°C).

Battery Removal/Installation:

1. Remove protective rubber boot.
2. Remove the screw on back plate and lift back plate off by hand.
3. Replace/install the battery per the polarity indicators.
4. To reassemble replace the back plate, screw and protective rubber boot.

A "LOW BAT" descriptor indication will appear on the display when batteries need to be replaced.

NOTE: *The battery is included but not installed. Please install battery prior to use!*