

Installation Instructions for 50440 Air Pump Eliminator

NOTE: This Air Pump Eliminator is for off-road use only.

1. Remove your factory accessory belt.
2. Remove the factory air pump from the bracket by removing the two bolts.
3. Disconnect the air tube coming off of the pump and plug it.
4. Install the Air Pump Eliminator in the factory location using the factory mounting bolts. Torque to factory recommended specifications.
5. Reinstall your factory accessory belt. Check belt alignment with other pulleys before starting vehicle.



1-800-345-4545 jeps.com