


92970218

Starter Solenoid  
(Not included  
with this kit)



To "I" on starter solenoid

12V ignition  
feed from  
ignition switch  
(Not included  
with this kit)

To ignition switch side of resistor

Ballast Resistor  
(Not included  
with this kit)

To coil side of resistor



Tach



To pulse terminal on tach (if so equipped)

To 2 way  
ignition  
module  
connector





This cavity is blank

To 4 way  
ignition  
module  
connector




Ignition  
Coil




To ignition  
coil

Distributor



To distributor  
connector



Ignition  
Module  
(Not included  
with this kit)



**American  
Autowire**

www.americanautowire.com 856-933-0801

Instructions for Ford Duraspark  
Ignition Harness

500918

92970218 instruction sheet rev 1.0 1/19/2015