

# MSD<sup>®</sup> IGNITION INSTALLATION INSTRUCTIONS

## MSD Shift Light PN 7552

### Parts Included In This Kit:

1 - Shift Light

**WARNING:** During installation, disconnect the battery cables. When disconnecting the battery, always remove the Negative cable first and install it last.

The MSD Shift Light features a bright LED that will alert you to shift at an rpm point. The Shift Light requires a 12 volt source (maximum of 18 volts) and ground. There is no polarity to the Light's two Yellow wires. This LED system is not sensitive to polarity, unlike other LED circuits.

### MSD PROGRAMMABLE DIGITAL IGNITIONS AND CONTROLLERS

Connect one of the Shift Light's Yellow wires to the shift light output wire of the MSD component. This will control the activation of the Light by supplying the ground. The other Yellow wire connects to a 12 volt source (It does not matter which Yellow wire).




Figure 1 Connecting to an MSD Digital Ignition or Controller.

# MSD IGNITION INSTALLATION INSTRUCTIONS

## CONVENTIONAL IGNITIONS

The PN 7552 can also be used with a conventional or performance ignition system, though an RPM Activated Switch, such as MSD's PN 8950, is required to drive the Light (Figure 2).




Figure 2 Connecting with an RPM Activated Switch.

### Service

In case of malfunction, this MSD component will be repaired free of charge according to the terms of the warranty. When returning MSD components for warranty service, **Proof of Purchase** must be supplied for verification. After the warranty period has expired, repair service is based on a minimum and maximum fee.

**All returns must have a Return Material Authorization (RMA) number** issued to them before being returned. To obtain an RMA number please contact MSD Customer Service at 1 (888) MSD-7859 or visit our website at [www.msdisignition.com/rma](http://www.msdisignition.com/rma) to automatically obtain a number and shipping information.

When returning the unit for repair, leave all wires at the length in which you have them installed. Be sure to include a detailed account of any problems experienced, and what components and accessories are installed on the vehicle. The repaired unit will be returned as soon as possible using Ground shipping methods (ground shipping is covered by warranty). For more information, call MSD Ignition at (915) 855-7123. MSD technicians are available from 7:00 a.m. to 6:00 p.m. Monday - Friday (mountain time).

### Limited Warranty

MSD IGNITION warrants this product to be free from defects in material and workmanship under its intended normal use\*, when properly installed and purchased from an authorized MSD dealer, for a period of one year from the date of the original purchase. This warranty is void for any products purchased through auction websites. If found to be defective as mentioned above, it will be repaired or replaced at the option of MSD Ignition. Any item that is covered under this warranty will be returned free of charge using Ground shipping methods.

This shall constitute the sole remedy of the purchaser and the sole liability of MSD Ignition. To the extent permitted by law, the foregoing is exclusive and in lieu of all other warranties or representation whether expressed or implied, including any implied warranty of merchantability or fitness. In no event shall MSD Ignition or its suppliers be liable for special or consequential damages.

\*Intended normal use means that this item is being used as was originally intended and for the original application as sold by MSD Ignition. Any modifications to this item or if it is used on an application other than what MSD Ignition markets the product, the warranty will be void. It is the sole responsibility of the customer to determine that this item will work for the application they are intending. MSD Ignition will accept no liability for custom applications.