



Part # 1515,15150- 1986-93 Ford Mustang 5.0L

Part # 1525,15250- 1994-95 Ford Mustang 5.0L

Part # 1511,15110- 1979-93 351 Windsor Mustang Swap

# BBK Shorty Headers



Special Tools

Required:

- No special tools required

Install Time:

Approximately  
2 Hours

Difficulty:

3 out of 5

Follow these instructions carefully to ensure correct fitment and operation.

## STEP 1

- Disconnect the negative battery terminal.

## STEP 2

- Remove the entire stock air inlet system from the vehicle, this is easily done by removing the hose clamp at the throttle body, the two mass-air mounting bracket bolts from the strut tower/inner fender well area, and the two filter box mounting nuts at the top edge of the factory box.

## STEP 3

- Remove the air injection tubes from the passenger side. ***NOTE!!! On 1994-1995 models, remove the steel EGR Tube mounted on the passenger side header, kit 1525 and 15250 include a new EGR Tube Assembly.***

## STEP 4

- Remove the spark plugs and spark plug wires from the vehicle.

## STEP 5

- Working from under the vehicle, remove the nuts connecting the H-Pipes to the factory exhaust manifolds and the nuts holding the mufflers to the H-Pipe and slide back a few inches for clearance.

## STEP 6

- Remove the stock exhaust manifolds and clean any gasket material from the heads. (Header removal and installation is done at the top of the engine compartment).

## STEP 7

- Using the gaskets provided start all the new header bolts before tightening the new headers.

## STEP 8

- Reverse the previous steps to complete the installation.



Join our Facebook page  
[www.facebook.com/bbkperformance](http://www.facebook.com/bbkperformance)



Follow us on Twitter  
[@bbkperformance](https://twitter.com/bbkperformance)



Check us out on Youtube  
[www.youtube.com/bbkperformance](http://www.youtube.com/bbkperformance)

[WWW.BBKPERFORMANCE.COM](http://WWW.BBKPERFORMANCE.COM)

For any questions, email us:  
[tech@bbkperformance.com](mailto:tech@bbkperformance.com)

installation instructions

1

**IMPORTANT:** All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance Inc. accepts no responsibility for injuries or damage caused by or during the installation of this product.

INS-011