



# INSTALLATION INSTRUCTIONS

## Part Number: HA-1121

This filter fits: SEE CATALOG FOR CURRENT APPLICATIONS

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter can be used in a stock machine, with no modifications required. If any engine modifications have been made tuning/jetting adjustments may be required. There are special installation instructions, so please follow the procedures outlined below to ensure the K&N® Filtercharger® seals properly.

**If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.**

### INSTALLATION:

- 1.) Open air box and unscrew the six screws holding the stock air filter. (Fig.1)
- 2.) Remove the six screws from the stock air filter by pushing it out from the back side. (Fig.2)
- 3.) Apply the six supplied spacers into the K&N air filter. (Fig.3)
- 4.) Clean all sealing surfaces in the air box.
- 5.) Install the K&N air filter (filter can only fit one way) insert the six screw and tighten filter into air box to complete installation. (Fig.4)

**THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.**




Fig. 1



Fig. 2



Fig. 3




Fig. 4

### CLEANING:

K&N Engineering, Inc., suggests checking the air filter element periodically for excessive dirt build-up. Depending on your driving conditions, we recommend cleaning your air filter every 50,000 miles. To clean and re-oil, purchase our filter Recharger® service kit, part number 99-5050 or 99-5000 and follow the easy instructions.