





**757-842-6497**  
**WWW.JLOSC.COM**

**J&L 3.0 Oil Separator**  
**(2011-17 Mustang GT, 2012-13 Boss & 2015-2020 GT350 Driver Side)**  
**Part Number: 3011D**

**Installation Instructions**

**Please review complete instructions prior to installing.**

Step#	
<b>1</b>	<b>Verify you have all of the following parts included in the kit:</b> (1) J&L Oil Separator, (1) Angled mounting bracket, (2) Fine thread machine screws, (1) Black mounting clamp, (1) ¼-20x ½" bolt, (2) ¼-20 nuts (1 extra in case you drop one)
<b>2</b>	<b>Gather all of the following tools needed for the installation:</b> Phillips screwdriver, 7/16 socket and wrench
<b>3</b>	Remove factory PCV line by pulling tabs and pulling it off of the engine and intake system. 
<b>4</b>	Use supplied bolt and nut to mount J&L Bracket to pre-existing hole on fender apron tab. <b>2011-14 SEE STEP #6</b>
<b>5</b>	 <p>Mount Oil Separator to J&amp;L Bracket with the two supplied machine screws. The longer hose will be closest to the valve cover. Route short hose to valve cover and route long hose to the intake tube.</p>

6

## 2011-2014 MOUNTING

You have 2 options for mounting the Separator.

For both the sound tube rubber mount will need to be removed from the tab.

1) Using the included black mounting clamp, install on the BACK side of the tab on the driver side strut tower. Bolt will be on the bottom. Hold it tight and flat against the tab and tighten the bolt. **DO NOT OVER TIGHTEN, JUST SNUG SO IT DOESN'T MOVE.**



Use the supplied  $\frac{1}{4}$ -20x $\frac{1}{2}$ " bolt and attach J&L Bracket to the black mounting clamp using the smaller hole as shown below:



**OR**

2) You can drill  $\frac{1}{4}$ " hole and use the supplied nut and bolt to mount the J&L bracket to the tab.

Now go back and follow from STEP 5

To properly clean the filter in the Oil Separator, spray any degreaser or solvent through it and let it air dry. Clean it every 10,000 miles.

Thank you for your business. If you have any questions, please e-mail [info@JLosc.com](mailto:info@JLosc.com) or call 757-842-6497. Our hours are Monday-Friday, 8:00am – 4:30pm Eastern Time.

**J&L Oil Separator co. Lifetime Satisfaction Guarantee. We want you to be a J&L customer for life!** Your new J&L product is warranted to be free from defects in materials and workmanship for the life of the *original retail purchaser*, subject to the limitations contained in our warranty found here. [www.JLosc.com/warranty](http://www.JLosc.com/warranty)

We guarantee workmanship and even a pathway to discounted upgrades for substantially improved items.

**Return Policy:** All returns will be subject to a 10%-25% restocking fee. Please visit [www.JLosc.com](http://www.JLosc.com) for complete return policy.

**Disclaimer:** J&L Oil Separator co. makes no warranties whatsoever, expressed, or implied, oral or written to any purchasers, except the warranty above. J&L Oil Separator co. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by J&L Oil Separator co. agree to hold harmless and indemnify J&L Oil Separator co. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to J&L Oil Separator co. for any claims arising out of use of its products.