





757-842-6497
WWW.JLOSC.COM

**J&L Oil Separator, Passenger Side
(2021-2023 Jeep Wrangler 392)
#3072P**

Installation Instructions

**Install video available at our website www.JLosc.com Search: 3072P and click videos.
Please review complete instructions prior to installing.**

Step#	
1	Verify you have all of the following parts included in the kit: (1) J&L Oil Separator (1) J&L Mounting Bracket, (2) Fine Thread Machine Screws
2	Gather all of the following tools needed for the installation: 10mm socket and ratchet and Phillips screwdriver. A Pair of pliers.
3	Remove the factory PCV hardline from both rubber connection points. You may need to twist the rubber ends with pliers to break seal on connections. Leave rubber connections on! 
4	Mount J&L Oil separator to J&L bracket with supplied screws
5	Remove 10mm Nut from behind coolant tank, slide J&L bracket over stud and reinstall nut. Before tightening nut, be sure oil separator has space between the coolant tank and firewall. 

Route long hose behind PCV box and make connection at front of intake manifold. Connect short hose to PCV box.



6

To properly clean the filter in the Oil Separator, spray any degreaser or solvent through it and let it air dry. Clean it every 10,000 miles.

Thank you for your business. If you have any questions, please e-mail info@JLosc.com or call 757-842-6497. Our hours are Monday-Friday, 8:00am – 4:30pm Eastern Time.

J&L Oil Separator co. Lifetime Satisfaction Guarantee. We want you to be a J&L customer for life! Your new J&L product is warranted to be free from defects in materials and workmanship for the life of the *original retail purchaser*, subject to the limitations contained in our warranty found here. www.JLosc.com/warranty

We guarantee workmanship and even a pathway to discounted upgrades for substantially improved items.

Return Policy: All returns will be subject to a 10%-25% restocking fee. Please visit www.JLosc.com for complete return policy.

Disclaimer: J&L Oil Separator co. makes no warranties whatsoever, expressed, or implied, oral or written to any purchasers, except the warranty above. J&L Oil Separator co. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by J&L Oil Separator co. agree to hold harmless and indemnify J&L Oil Separator co. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to J&L Oil Separator co. for any claims arising out of use of its products.