



## **INSTALLATION INSTRUCTIONS**

**P/N 23920 - ACCUMULATOR MOUNT  
USE WITH MOROSO P/N 23900 AND 23901 ACCUMULATORS  
P/N 23921 - ACCUMULATOR MOUNT  
USE WITH MOROSO P/N 23902 AND 23903 ACCUMULATORS**

Use Moroso Accumulator instructions for proper installation and positioning of the Accumulator. After you have selected the location where it is to be installed, use one of the mounting options listed below.

**NOTE:** When positioning the Mounting Brackets and Clamps, be sure to place them on the positioning decals provided on the Accumulator. This will ensure that under tightening, the accumulator tube does not deform.

### **INSTALLATION OPTION # 1**

Weld two 1/8" or thicker steel plates to a roll bar or other suitable mounting surface. The plates will be used to securely fasten the Accumulator in the location you have selected. In each steel plate, drill two 11/32" holes 3.5" apart where you want the mounting brackets positioned. Bolt the two brackets to the mounting plates with 5/16" bolts, nuts, and lock washers. You are now ready to secure the Accumulator using the two steel clamps provided.

### **INSTALLATION OPTION # 2**

Mount the brackets to the roll cage or chassis tubing using two, 3.5" U-bolts (Not supplied). Be sure position U-bolts correctly (over positioning decals) and secure the Accumulator.

### **PARTS LIST:**

2 Steel Clamps with Mounting Brackets

**For Technical Assistance, Call Moroso's Tech Line at  
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time**

MOROSO PERFORMANCE PRODUCTS, INC  
80 CARTER DR • GUILFORD, CT 06437-2116  
Phone: (203) 453-6571 • Fax: (203) 453-6906