



## Installation Instructions for 60341 Ford Transmission Cooler Fitting Kit


### FITTING 1



### FITTING 2



### FITTING 3



### Installation Requirements

1. Identify the transmission return line as described in the transmission cooler instruction sheet.
2. Use JEGS thread sealant #555-28011 when installing fittings. Tighten 11-15 ft/lbs.

#### Deep Threaded Fitting

I.D. – 5/8" diameter, 3/4" long hex fitting in radiator. Radiator thread is 1/4" MPT.

Transmission line fitting is 1/2"-20 inverted flare with recessed internal threads.

1. Remove transmission line from fitting in radiator.
2. Remove fitting in radiator and reinstall on transmission line.
3. Thread fitting #1 into radiator and fitting #2 onto transmission line.

#### Duckbill Fitting

I.D. – Uses plastic retainer to attach steel transmission line to 11/16" diameter hex fitting in radiator. Radiator thread is 1/4" MPT.

1. Disconnect fitting from radiator.
2. Thread fitting #1 into radiator and fitting #2 onto transmission line fitting.

#### Aerostar and Explorer

I.D. – Two fitting variations are used:

1. 3/4" diameter, 13/16" long hex with recessed internal threads.
2. 7/8" diameter, 3/8" short hex.

1. Remove transmission line and fitting in radiator.
2. Thread fitting #3 into radiator.
3. Push transmission line fitting back and install hose.



1-800-345-4545 [jegs.com](http://jegs.com)