



DIRECTIONS # 651 SUZUKI SWIFT/GEO METRO

IMPORTANT: READ BEFORE INSTALLATION!!!

NOTE: For ease of installation back up vehicle on to car ramps, since suspension must be at normal ride height for proper installation.

STEP 1: Lubricate the inside of the D-bushings and place them around the mid-section of the bar. Next place the brackets over the D-bushings.

STEP 2: Locate the existing threaded holes in the bottom of the trunk well just to the rear of the suspension. With the bolts and washers provided fasten the brackets to the bottom of the trunk well. Tighten to approximately 20 Ft. Lbs. (Note: The bar should be positioned with the dip in the center of the bar downward and the arms pointing forward over the suspension arms).

STEP 3: Next locate the existing hole in the lower suspension arms. Assemble the end-links as shown in the illustration so as to connect the eye of the bar to the lower suspension arm. Tighten end-links just enough to slightly compress bushings. Do not over tighten end-links assemblies.

STEP 4: Check the bar for proper clearance in relation to other suspension components and other components that may interfere with the bar throughout suspension travel.

STEP 5: Road test the vehicle to familiarize yourself with the vehicles new handling. Since we cannot supervise your driving or installation we cannot be held responsible for more than the cost of the kit.

HARDWARE LIST:

2 RH 046C	Brackets
2 RH 612B	D-Bushings
4 RH 104	Flat Washers
4 RH 105	Flat Washers
4 RH 211	Bolts
2 RH 013	End-Links

DIRECTION 651

