


## Foldable Hitch Mounted Cargo Carrier (Aluminum) Operation Manual & Safety Instruction Model: 18100





## WARNING



- Do not exceed maximum weight capacity of 500lbs. when using 2" receiver bar.
- Distribute weight evenly on platform.
- This carrier is not intended for transporting humans.
- Do not carry loads wider or deeper than carrier.
- Do not carry flammable items on carrier.
- Do not allow exhaust fumes to blow directly on items. This is a FIRE HAZARD.
- CURT Manufacturing is not responsible for any damage if warnings are not heeded.

## **Part List**

Item No.	QTY	Description
(1)	2	Platform half
(2)	4	M10*30 Carriage Bolts
(3)	1	Flat Brace
(4)	2	M10*83 Carriage Bolt
(5)	14	M10 Locknut
(6)	1	Square tube bracket
(7)	1	5/8" ×3" Hexagon Head Screw
(8)	1	5/8"×70mm Clevis Pin
(9)	1	Foldable connection bar
(10)	1	hitch pin clip
(11)	2	Support Bridge
(12)	1	5/8" Locknut
(13)	2	Brace
(14)	8	M10*20 Carriage bolt

## Assembly:

- 1. Put the support tube bracket(6) upwards, then insert both halves of the platform (1) between support tube and flat brace (3), align platform angle side holes and connect with M10\*20 carriage bolt (14)and M10 locknut (5) (80% tightness).
- 2. Connect flat brace (3), support tube (6) and support bridge (11) with M10\*83 carriage bolts(4) and M10 locknuts(5) (80% tightness).
- 3. Connect the platform (1), brace (13) and support bridges (11) with M10\*30 carriage bolts (2) and M10 locknuts (5) (80% tightness).
- **4.** Align both halves of the platform (1), and then screw down all the bolts and locknuts.
- 5. Insert the foldable connection bar (9) into support tube bracket(6), align all the holes and lock big holes with 5/8"x3" hexagon head bolts (7) and 5/8" locknuts (12). 5/8"x70mm Clevis Pin (8) is needed for horizontal rotation and rotating 90 degrees, insert clip (10) securely into the hole in Clevis Pin (8).