



**EDELBROCK CRATE ENGINE
SUPERCHARGED FORD 5.0L COYOTE
Part #46770, 46880
GENERAL INSTALLATION INSTRUCTIONS**

PLEASE study these instructions carefully before beginning this installation. If you have any questions, please call our **Technical Hotline at: 1-800-416-8628**, 7:00 AM - 5:00 PM Pacific Standard Time, Monday through Friday.

Proper installation is the responsibility of the installer. Improper installation will void the manufacturer's warranty and may result in poor performance and engine or vehicle damage.

IMPORTANT NOTE: This instruction sheet provides general installation guidelines which can affect your warranty. Read it carefully. It is not our intent to cover each detail of installation here as the procedures are vehicle specific. We want to caution you that installing an engine is a complicated procedure that requires a good general knowledge of automotive mechanics. It is a good idea to refer to the factory service manual for your vehicle. If you are not confident that you can complete the engine installation successfully, we suggest you consider having it installed by an experienced mechanic.

CAUTION: This engine is NOT INTENDED for marine use. Not legal for use in pollution controlled vehicles.

DESCRIPTION: This crate engine is built using a Ford aluminum 5.0L block with a forged and balanced crankshaft, forged Manley H-Beam connecting rods and Mahle forged aluminum pistons which are then combined with Edelbrock's E-Force Supercharger to produce 700 horsepower and 606 ft.-lbs. of torque on 91 octane pump gas. Its compact design allows for a seamless swap into most platforms, eliminating the need for modifications to your engine bay or hood.

AVAILABLE VARIANTS:

- P/N 46770 - Supercharged Ford 5.0L Crate Engine, Complete With Electronics
- P/N 46880 - Supercharged Ford 5.0L Crate Engine, Complete Without Electronics

PRODUCT SPECIFICATIONS:

Displacement:	4.957L (302 ci)
Bore / Stroke	3.629" bore / 3.649" stroke
Horsepower:	700
Torque:	606
Compression:	9.5:1
Block:	New Ford Aluminum
Cylinder Heads:	Factory Aluminum 54.5 - 57.5cc
Supercharger:	Edelbrock E-Force
Pistons:	Mahle Forged Aluminum
Crankshaft:	Forged 4340
Camshaft Duration:	Intake: 260°; Exhaust: /263°
Camshaft Lift:	Intake: 12mm; Exhaust 11mm
Rocker Arms:	2:1 ratio
Spark Plugs:	Ford M-12405-M50 (.032 Gap)
Fuel Type:	<u>Requires 91 Octane At All Times</u>
Firing Order:	1-5-4-8-6-3-7-2
Maximum Rated RPM:	7200 RPM
Warranty:	2 Year/Unlimited Mileage

ANCILLARY PARTS REQUIRED FOR INSTALLATION

- Low Temperature Radiator (LTR)
 - #15405: Full Face Universal Fit
 - #15406: Compact Universal Fit
 - #15407: Compact, 16" x 16", Universal Fit
- LTR/Intercooler Plumbing
- Fuel Pump - A minimum fuel flow of 75gph @ 60psi differential pressure is required. *It is the responsibility of the customer to ensure that adequate fuel flow is achieved at the operating voltage of the fuel pump. Engine damage can occur if fuel flow is insufficient.*

- Fuel Pressure Regulator with Boost Reference.

GENERAL SUPERCHARGER PLUMBING INSTALLATION

- Determine the ideal mounting location for the intercooler heat exchanger (not included). It is important that the heat exchanger receives the coldest air possible, which means mounting it in front of the radiator, A/C condenser and any oil or trans cooler the vehicle might have equipped.

- Determine the ideal mounting location for the water pump. A universal mounting bracket has been supplied to simplify installation. ***Please note that the pump should be mounted no higher than the inlet of the heat exchanger.*** The inlet of the pump is in line with the axis of the pump motor, while the outlet extends out perpendicularly from the pump body.

- Determine the ideal mounting location for the intercooler reservoir tank. To simplify installation, a universal mounting bracket and a groove around the perimeter of the tank, for use with a large worm clamp, have been included.

NOTE: Be sure to mount the tank as high as possible to prevent air bubbles from accumulating in the cooling system.

- Refer to the diagram on Page 3 for the suggested intercooler plumbing (not included). Note that the intercooler routing can be inverted so that the pump and tank are mounted on the driver side. Regardless of component mounting locations, it is important that the correct direction of flow is maintained.

GENERAL HARNESS INSTALLATION

- Determine the ideal mounting location for the relay and fuse holder on the water pump harness. Connect the POSITIVE (+) lead to a CONSTANT +12V power source. Connect the GROUND (-) lead to a chassis ground. Connect the water pump connector to the electric water pump. Connect the factory female EVAP connector to the male EVAP connector on the water pump harness. Then plug the female end of the water pump harness onto the EVAP solenoid.

- Install the ACT Harness to the ACT sensor on the rear of the supercharger manifold. The female MAF adaptor connects to the

factory male MAF connector. The male MAF connector connects to the factory MAF sensor.

- If using the Ford Racing Electronic Throttle Crate Engine Controls Pack (#46770 Only), please refer to the installation instructions included with the controls pack for installation guidelines.

ENGINE OIL: This crate engine is shipped dry without engine oil. Make sure to add the recommended Ford oil prior to priming the engine oil. The engine oil must be changed no more than 300 miles after break-in. A full synthetic SAE 5W-50 is highly recommended after the break-in period. Engine oil capacity is eight (8) quarts.

START-UP: The engine should be primed with oil prior to starting. Install an oil pressure gauge to the existing oil pressure sensor. Remove the spark plugs and disconnect the engine control unit as well as the injector wires. **NOTE: Make sure ignition and fuel are not provided to the engine.** Once fuel and spark have been disabled, crank the engine using the starter for 10 seconds, checking the oil gauge for oil pressure. If no pressure is indicated, wait 30 seconds and crank again for 10 seconds. Repeat this process until oil pressure is indicated on the gauge. Reconnect the engine control unit, injector wires and reinstall spark plugs. Start the engine and listen for any uncommon sounds. If uncommon sounds are not present, run the engine at idle until it reaches operational temperatures.

OIL PAN CLEARANCE: Make sure you have adequate subframe and ground clearance before installing the engine.

FLYWHEELS AND FLEXPATES: The 5.0L Coyote engines use special flexplates or flywheels (included). See below:


Flexplate:

Ford Part Number:	BL3Z6375A (OEM)
Converter Bolt Pattern:	8 Bolt, 11.5"
Outside Diameter:	14.25"
Starter Ring Gear Tooth:	164
Torque Spec:	177 lb-in, Plus additional 60°


Flywheel:

Ford Part Number:	BR3Z6375D (OEM)
Flywheel Bolt Pattern:	8 Bolt
Outside Diameter:	14.25"
Clutch Bolt Pattern:	6 Bolt, 10.5/11.5"
Starter Ring Gear Tooth:	164
Flywheel Torque Spec:	177 lb-in, Plus additional 60°
Clutch Torque Spec:	35 ft-lbs, Plus additional 60°

Harness Layout



Supercharger Intercooler Routing Diagram



Edelbrock LLC • 2700 California St. • Torrance, CA 90503
Tech Line: 1-800-416-8628 • Office Line: 310-781-2222