



Installation Instructions

Caliper Kit

Item # CC0001

Applications: 1965-67 Ford & Mercury Cars



Thank you for choosing Leed Brakes for your automotive product needs. Before you begin your installation please inspect all parts and review the installation instructions. If you have any missing or damaged parts or if you have any questions regarding the fitment of this kit on your specific vehicle please contact our customer service team at (716) 852-2139 before beginning your installation

Tools required for a safe and smooth installation:

Proper Jack & Jack Stands, Tube Wrenches, Standard Socket Set, Standard Wrench Set, Torque Wrench, Lug Wrench, Pliers, Mallet, Brake Fluid, Brake Cleaner, Wheel Bearing Grease.

Fitment Notes:

This kit is a direct replacement for all factory disc brake cars from 1965-1967 equipped with Kelsey Hayes 4 Piston Calipers utilizing D11 brake pads.

Factory Caliper Removal:

1. Safely raise the vehicle off the ground until the wheels are clear and spin freely. Support the vehicle using the appropriate Jack Stands and remove the front wheels.
2. Since you will be replacing the factory rubber brake hoses, they can be clamped off with hose pliers or vice grips. Using a tube wrench loosen, but do not fully disconnect the hard brake line from the flex hose at the frame rail bracket.
3. Loosen and remove the caliper mounting bolts that secure the factory caliper to the mounting bracket. These are special shoulder bolts and will be reused with the new calipers. Next disconnect the flex hose from the hard brake line and lift the caliper assembly off the rotor. To stop brake fluid from draining cap the end of the hard line with a rubber or silicone vacuum cap. ***Be very careful not spill any brake fluid on any painted surfaces as it will damage your paint.***

Caliper Installation:

1. The calipers will be installed in the same position as the factory calipers. **Photo 1**
2. Now would be a good time to inspect and replace or repack your wheel bearings and seals as needed.
3. **Calipers** will arrive preloaded and ready for installation. If you need to replace the pads in the future the pads are standard **D11** Mustang brake pads. **Photo 2**
4. Install the **calipers** using the **shoulder bolts** removed earlier. Torque to 45-60 ft. lbs. If the caliper interferes with the splash shield minor trimming of the splash shield may be required. **Photo 3 & 4**
5. Once the calipers are installed spin the rotors to insure there is no interference between the caliper and the rotor.
6. Install the **flex hose** to the **caliper** using (1) **copper washer** between the hose fitting and the caliper. **Photo 5**
7. Install the other end of the flex hose to the frame bracket and retain it using the **horseshoe clip** provided. Reconnect the original hard line and tighten using a tube wrench.
8. If needed install the **brass brake line adapters** provided into the rubber hose and connect your factory hard brake line. Not all cars will need these adapters, if your car is equipped with a 3/8-24 fitting on your hard line you can install your hard line directly to the brake hose.
9. Turn the wheels thru a complete left and right turn to insure there is no interference with the new brake system and any suspension or body components. Also check the rubber hoses during this operation to ensure the hoses are not binding or twisting. If your rubber hoses bind during a turn, you could experience loss of braking while driving. If it looks like they are binding remove the horseshoe clip and reposition the brake hose until it no longer binds.

Bleeding the vehicles braking system:

We recommend that the brake system is bled using a gravity bleed method. While there are many ways to bleed a system this way is less likely to introduce air in the system causing a spongy pedal. Whenever bleeding your system, you must keep an eye on your fluid level. If your master runs dry you will have to bench bleed the master again.

1. Remove the cap from the master cylinder. If the fluid is dark and contaminated, it's a good idea to remove most of the fluid and replace it with clean DOT 3 or DOT 4 fluid before you begin bleeding the new calipers.
2. Starting at the right rear wheel cylinder or caliper attach a clear hose to the bleeder with the other end in a clear container.
3. Open the bleeder and observe the fluid flow. It may take a couple of minutes for the fluid to flow with a new system. Once the fluid begins to flow let it drip until you do not see any air.
4. Move to the left rear wheel, repeat step 3.
5. Move to the right front wheel, repeat step 3.
6. Move to the left front wheel, repeat step 3.
7. Repeat steps 2 thru 6 once more.
8. Install the lid on the master cylinder.
9. Pump the brake pedal until you achieve a firm pedal.
10. Remove lid on master cylinder & check fluid level
11. Repeat steps 2 thru 6 to ensure all air has been removed and clean fluid is coming out of the bleeders.

Once you feel you have successfully removed all air from your brake system check all fittings and lines for leaks and verify all fasteners are tight. Install your wheels and spin them to insure they still spin freely making sure the caliper doesn't interfere with the wheel and your brakes are not dragging or locked up.


You may now take your vehicle for a test drive in a safe area. We recommend that you drive the vehicle with light to medium application of the brakes for the first 150-200 miles. This will allow your brake pads to properly seat to your rotors to insure optimal braking performance.

If you have any questions, please call our tech line at (716) 852-2139

Thank you for purchasing from Leed Brakes we hope you have had an enjoyable experience.

Splash Shield Interference Reference Guide

From time to time, we experience an interference issue between the caliper and the splash shield. It is understood that this was an issue on the assembly line with the factory disc brake cars as well. If you do experience interference with your caliper and splash shield, please modify the splash shield as outlined below.





Installation Photos

Disc Brake Conversion Kit




Photo 1





Photo 2



← Front of car

Photo 3



Front of Car →

Photo 4




Photo 5