



**OIL PUMP STUD
P/N 38150**

INSTALLATION INSTRUCTIONS

PARTS LIST

- 1 7/16" – 14 X 7/16 – 20 Stud
- 1 7/16" Hardened Washer
- 1 7/16" – 20 Nut

INSTALLATION:

1. Run a 7/16"-14 tap through the existing bolt hole in the rear main cap to clean the threads.
2. Install the course end (7/16"-14) of the stud into the rear main cap and torque to 10-15 ft/lbs.
3. Mount the oil pump to the rear main cap and put a few drops of oil on the studs and washers before threading on the nuts.
4. Install the hardened washer first and then the 7/16"-20 nut.
5. Torque to 50 ft/lbs. 38150INST

**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time**
MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Visit Us At www.moroso.com



**OIL PUMP STUD
P/N 38150**

INSTALLATION INSTRUCTIONS

PARTS LIST

- 1 7/16" – 14 X 7/16 – 20 Stud
- 1 7/16" Hardened Washer
- 1 7/16" – 20 Nut

INSTALLATION:

1. Run a 7/16"-14 tap through the existing bolt hole in the rear main cap to clean the threads.
2. Install the course end (7/16"-14) of the stud into the rear main cap and torque to 10-15 ft/lbs.
3. Mount the oil pump to the rear main cap and put a few drops of oil on the studs and washers before threading on the nuts.
4. Install the hardened washer first and then the 7/16"-20 nut.
5. Torque to 50 ft/lbs. 38150INST

**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time**
MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Visit Us At www.moroso.com



**OIL PUMP STUD
P/N 38150**

INSTALLATION INSTRUCTIONS

PARTS LIST

- 1 7/16" – 14 X 7/16 – 20 Stud
- 1 7/16" Hardened Washer
- 1 7/16" – 20 Nut

INSTALLATION:

1. Run a 7/16"-14 tap through the existing bolt hole in the rear main cap to clean the threads.
2. Install the course end (7/16"-14) of the stud into the rear main cap and torque to 10-15 ft/lbs.
3. Mount the oil pump to the rear main cap and put a few drops of oil on the studs and washers before threading on the nuts.
4. Install the hardened washer first and then the 7/16"-20 nut.
5. Torque to 50 ft/lbs. 38150INST

**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time**
MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Visit Us At www.moroso.com



**OIL PUMP STUD
P/N 38150**

INSTALLATION INSTRUCTIONS

PARTS LIST

- 1 7/16" – 14 X 7/16 – 20 Stud
- 1 7/16" Hardened Washer
- 1 7/16" – 20 Nut

INSTALLATION:

1. Run a 7/16"-14 tap through the existing bolt hole in the rear main cap to clean the threads.
2. Install the course end (7/16"-14) of the stud into the rear main cap and torque to 10-15 ft/lbs.
3. Mount the oil pump to the rear main cap and put a few drops of oil on the studs and washers before threading on the nuts.
4. Install the hardened washer first and then the 7/16"-20 nut.
5. Torque to 50 ft/lbs. 38150INST

**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time**

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Visit Us At www.moroso.com



**OIL PUMP STUD
P/N 38150**

INSTALLATION INSTRUCTIONS

PARTS LIST

- 1 7/16" – 14 X 7/16 – 20 Stud
- 1 7/16" Hardened Washer
- 1 7/16" – 20 Nut

INSTALLATION:

1. Run a 7/16"-14 tap through the existing bolt hole in the rear main cap to clean the threads.
2. Install the course end (7/16"-14) of the stud into the rear main cap and torque to 10-15 ft/lbs.
3. Mount the oil pump to the rear main cap and put a few drops of oil on the studs and washers before threading on the nuts.
4. Install the hardened washer first and then the 7/16"-20 nut.
5. Torque to 50 ft/lbs. 38150INST

**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time**

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Visit Us At www.moroso.com



**OIL PUMP STUD
P/N 38150**

INSTALLATION INSTRUCTIONS

PARTS LIST

- 1 7/16" – 14 X 7/16 – 20 Stud
- 1 7/16" Hardened Washer
- 1 7/16" – 20 Nut

INSTALLATION:

1. Run a 7/16"-14 tap through the existing bolt hole in the rear main cap to clean the threads.
2. Install the course end (7/16"-14) of the stud into the rear main cap and torque to 10-15 ft/lbs.
3. Mount the oil pump to the rear main cap and put a few drops of oil on the studs and washers before threading on the nuts.
4. Install the hardened washer first and then the 7/16"-20 nut.
5. Torque to 50 ft/lbs. 38150INST

**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time**

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906

Visit Us At www.moroso.com