

POWERGLIDE TRANSMISSION PAN P/N 42000

PARTS LIST


- 1 Transmission Pan
- 2 Magnetic Drain Plugs
- 1 Filter Spacer
- 2 Spacer Gaskets

2 - 1/4" -20 x 1.75 HHCS

2 - 1/4" Split Washers

14 - Serrated Flange Hex Bolts

- Drain Fluid from transmission and remove old pan.
- Clean any old gasket material from the pan-mounting surface.
- Remove filter, clean thoroughly or replace with a new one. Reinstall the filter with the supplied Filter Spacer, Gaskets and 1/4"-20 HHCS and Split Washers (see diagram below). Place a Gasket between the filter and the Filter Spacer and the other Gasket between the Filter Spacer and the mounting area. Tighten with the 1/4"-20 Hex Head Cap Screws and Split Washers to 10 ft.-lbs.
- Place a new gasket on the pan rail, tighten the pan with supplied Serrated Flange Hex Bolts. Torque to 10 ft.-lbs. (Note: Moroso Performance does not recommend using any type of sealer on the gasket, small pieces may dislodge and clog the transmission or transbrake. Check that Drain Plugs are tight.
- The Moroso Transmission Pan holds more fluid than a stock shallow sump type pan, so be certain to fill your transmission to the proper level as indicated on the dipstick. Also, this pan is equipped with a transmission cooling return fitting for applications needing one.



For Technical Assistance, Call Moroso's Tech Line at (203) 458-0542,458-0546 8:30am - 5:00pm Eastern Time

MOROSO PERFORMANCE PRODUCTS, INC. 80 CARTER DR • GUILFORD, CT 06437

Phone: (203) 453-6571 • Fax: (203) 453-6906




POWERGLIDE TRANSMISSION PAN P/N 42000

PARTS LIST

- 1 Transmission Pan
- 2 Magnetic Drain Plugs
- 1 Filter Spacer
- 2 Spacer Gaskets

- 2 1/4" -20 x 1.75 HHCS
- 2 1/4" Split Washers
- 14 Serrated Flange Hex Bolts
- Drain Fluid from transmission and remove old pan.
- Clean any old gasket material from the pan-mounting surface.
- Remove filter, clean thoroughly or replace with a new one. Reinstall the filter with the supplied Filter Spacer, Gaskets and 1/4"-20 HHCS and Split Washers (see diagram below). Place a Gasket between the filter and the Filter Spacer and the other Gasket between the Filter Spacer and the mounting area. Tighten with the 1/4"-20 Hex Head Cap Screws and Split Washers to 10 ft.-lbs.
- 4. Place a new gasket on the pan rail, tighten the pan with supplied Serrated Flange Hex Bolts. Torque to 10 ft.-lbs. (Note: Moroso Performance does not recommend using any type of sealer on the gasket, small pieces may dislodge and clog the transmission or transbrake. Check that Drain Plugs are tight.
- The Moroso Transmission Pan holds more fluid than a stock shallow sump type pan, so be certain to fill your transmission to the proper level as indicated on the dipstick. Also, this pan is equipped with a transmission cooling return fitting for applications needing one.



For Technical Assistance, Call Moroso's Tech Line at (203) 458-0542, 458-0546 8:30am - 5:00pm Eastern Time

MOROSO PERFORMANCE PRODUCTS, INC. 80 CARTER DR • GUILFORD, CT 06437 Phone: (203) 453-6571 • Fax: (203) 453-6906