



# D5501 Installation Instructions 1994-1999 Dodge 1/2 Ton 4WD & 1994-2002 Dodge 3/4 Ton 4WD Front Extended Sway Bar Links

Live Chat @ [www.zoneoffroad.com](http://www.zoneoffroad.com) • Website [www.zoneoffroad.com](http://www.zoneoffroad.com) • Email [tech@zoneoffroad.com](mailto:tech@zoneoffroad.com) • Call 888.998.ZONE

**Read and understand all instructions and warnings prior to installation of product and operation of vehicle.**

### Difficulty Level

easy (1) 2 3 4 5 difficult

Estimated installation: .5 hours

### » PRODUCT SAFETY WARNING

Certain Zone Suspension Products are intended to improve off-road performance. Modifying your vehicle for off-road use may result in the vehicle handling differently than a factory equipped vehicle. Extreme care must be used to prevent loss of control or vehicle rollover. Failure to drive your modified vehicle safely may result in serious injury or death. Zone Offroad Products does not recommend the combined use of suspension lifts, body lifts, or other lifting devices.

You should never operate your modified vehicle under the influence of alcohol or drugs. Always drive your modified vehicle at reduced speeds to ensure your ability to control your vehicle under all driving conditions. Always wear your seat belt.

**\*Important\* Verify you have all of the kit components before beginning installation.**

### Kit Contents

Qty	Part		
2	Sway bar U -brackets	2	12mm x 75mm bolt
2	Sway bar links (7.5")	2	12mm lock nut
2	Hourglass bushings EB1 - 5/8" ID	2	12mm flat washer
2	Hourglass bushings EB1 - 3/4" ID	2	7/16" USS washer
2	Sleeve - lower (3/4" x 12mm ID x 1.98")	2	5/8"-11 nylock nut
2	Sleeve - upper (5/8" x 10mm ID x 1.38")	2	5/8" SAE washer
1	Bolt pack	2	3/8"-16 x 2-1/4" bolt
		4	3/8" SAE washer
		2	3/8"-16 lock nut

### Pre-Installation Note

1. This kit is intended for use on vehicles with 4-6" of lift that have a standard eye mount at the axle.

### Installation Instructions

1. Part the vehicle on a clean, flat surface and block the rear wheels for safety.
2. Remove the sway bar links from the vehicle. **Figure 1**




Figure 1

3. Install the new sway bar links with clevis bracket at the sway bar. The small diameter bushing and sleeve go into the bolt on clevis. The sway bar links should offset in towards the sway bar with the 12mm hardware at the axle and the 3/8" hardware at the clevis. Figure 2



Figure 2

4. Torque the 3/8" hardware to 35 ft-lbs. and the 12mm hardware to 55 ft-lbs.
5. Check all hardware after 500 miles.